Order No. V4325 - Configurator Programming Assembly

This assembly is only for use with Clack Configurator Software Version 9.x.x.x or higher.
(Available for free download from www.clackcorp.com/downloads/170-V921.zip)

Clack Configurator, Version 9.0.0.21 or higher, should first be installed on the computer prior to initially plugging in the V4325 Configurator Programming Assembly.

Plug the V4366 USB cable into any available computer USB port.
A "new hardware found" window may pop up if this is the intial time that it has been plugged into this PC. Regardless of what Windows operating system has been installed on this computer, the proper driver will be automatically installed.

The V4189 Ribbon Cable plugs into either the V4184-01 or V4159 Adapter Board.
Plug either the V4184-01 Adapter Board OR V3510-01 Adaper Cable onto the Clack Control to be configured.
(Depending on the control to be configured, either adapter, or in some cases V4159, may be used)

NOTE:
If Windows did not recognize that new hardware was connected:
- Make sure the V4366 USB cable is properly plugged into the USB port on the computer.
- Try another USB port.
- Uninstall and then reinstall the configurator program.

Insert end of cable through housing to provide strain relief.

V4325 COMPLETE CONFIGURATOR ASSEMBLY

V3466 O-RING (located inside housing)

V4366 USB CABLE

V3513 SCREWS

V3512 ADAPTER HOUSING

V4189 RIBBON CABLE

V3510-01 ADAPTER CABLE

V4159 10 PIN ADAPTER BOARD

V4184-01 20 PIN ADAPTER BOARD